

Controls and Connections

HEADBAND / HELMET MOUNTING CLIPS Depending on the model, the headse may be furnished with mouting clips for attaching to a hard hat (SPM-700-HMB), an over-the-head band (SPM-800-OHB) or a behind-the-head band (SPM-900-EMB)

> The PTT button on the BTH-900 is different than the BTH-700 and BTH-800

> > MUFF EARPHONES

speakers.

Received calls are heard through these Headset



BTH-800

BTH-900 POWER BUTTON / STATUS LED

PHONE BUTTON

When the Headset is paired with a cellular telephone, this button can be used to manage telephone functions such as answering or hanging up a call.

ADJUSTABLE BOOM MICROPHONE The Muff Headset boom microphone picks up the user's voice audio to send

CHARGING THE HEADSET

The PRYMEBLU Muff Headset has an internal Lithium Ion rechargeable battery pack which must be charged prior to operation. A fully charged battery will provide approximately 10 hours (or more) of operation before needing to be recharged. However, operating time can vary depending on usage and the condition of the battery pack. Recharge the battery regularly.

To charge the PRYMEBLU Headset:

1. Ensure the PRYMEBLU Headset is turned off using the Power Button.

2. Plug the supplied wall charger into a standard 120 volt AC outlet.

3. Plug the charge cable into the AC wall charger and then into the charge jack on the Headset. You will need to remove the protective rubber cover that is inserted into the charge jack. (To prevent dust and moisture from damaging your Headset, always ensure this cover is in place when you are not charging the Headset.)

4. Once the charging process has begun, the LED indicator on the Headset will show a continuous red light. When the battery is done charging, the LED light will turn off.

5. Typical charge time is approximately 4 hours. Actual charge time will vary depending on several factors including the battery's charge state, condition, and age.

6. Disconnect the charger from the lapel mic when charging is completed.

Charging Cautions:

- Use only the wall charger supplied by the manufacturer. Do not use any other charger. - Do not use a wall charger that appears to be damaged. (Example: frayed wires, melted plastic, etc.) Contact PRYME to get a new manufacturer-approved replacement charger.

- Do not tamper with or modify the Headset or charger.

- Always turn the power switch to the off position when charging the Headset.

P-CBL-USB-MICRO charger cable and P-CHA-BT-USB wall charger included with the Headset.



PAIRING THE HEADSET WITH A PRYMEBLU ADAPTER OR CELLULAR TELEPHONE

USB CHARGE JACK

This micro-USB jack is used to connect the supplied charge cable to the Headse in order to recharge the device's internal

lithium-ion battery pack.

2

Before you can use the PRYMEBLU Muff Headset, it must be paired with the PRYMEBLU BT adapter and/or cellular telephone that you wish to use.



To pair the Headset with a PRYMEBLU BT radio adapter:

1. Begin by first making sure that the Headset, PRYMEBLU radio adapter, and the two-way radio the adapter is connected to are all powered off. You should also power off any nearby BT devices. 2. Place the PRYMEBLU radio adapter into pairing mode by following the instructions that were provided with that device. On most PRYMEBLU adapters this is done by pressing and holding the PTT/Multifunction button on the adapter while turning the two-way radio on. Continue to hold the button down until the LED indicator on the adapter shows two blue flashes every second.

3. Press and hold down the Power Button on the PRYMEBLU Muff Headset for five seconds, until the LED on the Headset flashes RED-BLUE-RED-BLUE continuously in sequence. The Headset is now in pairing mode. 4. After a few seconds, the two devices should synch to one another. Once the Headset and PRYMEBLU radio adapter are paired with each other the status LED on the adapter will show a constant blue light for three seconds. The LEDs on both the adapter and Headset will then show one blue flash every few seconds. 5. If the PRYMEBLU radio adapter does not detect the Headset within 60 seconds of being put into pairing mode,

the adapter will exit the pairing mode and resume normal operation without synching to the 6. Once successfully paired, you will be able to operate your 2-way radio using the PRYMEBLU Muff Headset.

To pair the Muff Headset with a cellular telephone:

The PRYMEBLU headset is capable of working with a BT-enabled cellular telephone.

1. When pairing the Headset with a cellular phone, first make sure that the headset and all other nearby BT devices are powered off before beginning.

2. Press and hold down the Power Button on the headset for five seconds, until the LED on the adapter flashes RED-BLUE-RED-BLUE continuously in sequence. The headset Headset is now in pairing mode. 3. Activate the BT feature on your phone.

4. Activate the "scan/discover new BT devices" feature on the phone. The exact steps needed to do this will vary depending on the brand/model of phone you are using.

5. Select the Headset from the list of BT devices shown on your phone. If the phone asks for a passcode. enter "0000". The phone may also prompt you to confirm the connection.

6. After a few seconds, the two devices should synch to one another. Once the PRYMEBLU Headset and phone are paired with each other, the status LED on the microphone will revert back to a single blue flash every few seconds

7. Once successfully paired, you will be able to make and receive telephone calls using the Headset.

Reconnecting a Previously Paired Headset and Radio Adapter/Cellular Phone

Once the PRYMEBLU Muff Headset and BT radio adapter and/or cellular telephone have been successfully paired together, both devices will remember that connection. The Headset and radio adapter/phone will attempt to reestablish their link whenever they are both powered on and in within range of each other. Re-establishing this connection can take 10-60 seconds.

TESTING AND USING THE PRYMEBLU MUFF HEADSET

Once your Headset and PRYMEBLU radio adapter and/or cellular phone have been paired together:

Received signals will be heard through the speakers in the PRYMEBLU Muff Headset. The volume of received calls can be adjusted using the Volume Up and Volume Down buttons on the Headset or the volume control on the two-way radio or cellular phone.

The operator's voice is picked-up by the boom microphone in the PRYMEBLU Muff Headset..

Push-to-Talk can be activated one of several different ways:

By pressing and holding the PTT button on the PRYMEBLU Muff Headset.

• By pressing and holding the Talk/Multifunction button on the PRYMEBLU Adapter.

Using an optional wired PTT that is plugged into the PRYMEBLU Adapter.

Using an optional PRYMEBLU Wireless BT PTT (model BT-PTT2, sold separately). Note that if you are
using a PRYMEBLU BT-PTT2, you will first need to pair the radio adapter with the PTT using the
instructions located in the PRYMEBLU PTT User's Guide.

Telephone functions are provided by using the Headset's Phone Button.

Call State	Button Press	Function
Incoming call	Press Phone Button once	Answer call
Incoming call	Press and hold Phone Button for 5 seconds	Reject call
On a call	Press Phone Button once	Hang up call
No call	Double press Phone Button	Redial last number

5

You can also activate your phone's voice dialing feature by pressing and holding the Phone Button on the side of the Headset for three seconds. (This function works only when the microphone is NOT also connected to a two-way radio.)

When the Headset is paired to a MP3 music player or to a cellular phone only, the following buttons are remapped for playing music.

Button Press	Function
Phone Button	Play/Pause Music
Volume Up	Adjust music volume up
Volume Down	Adjust music volume down
Double-press Volume Up	Skip to next track
Double-press Volume Down	Skip to previous track

STATUS LED MESSAGES

The meanings of the various status LED messages shown by the PRYMEBLU Muff Headset are shown on the following table:

LED INDICATION	MESSAGE MEANING
No indication	Device is off
Blue-Red-Blue-Red continuous	Pairing mode
Two short blue flashes	Device turned on
Three red flashes, then off	Device turned off
One blue flash every 2 seconds	Not paired or link lost
One blue flash every 6 seconds	Normal (paired) operation
Continuous red when PTT pressed	PTT operation
One red flash every 6 seconds	Low battery
Continuous red (when connected to charger)	Charging
No indication (when connected to charger)	Charging is finished

SPECIFICATIONS

Dimensions:	220mm X 130mm X 90mm (SPM-700-HMB, SPM-800-OHB)
	240mm X 230mm X 160mm (SPM-900-EMB)
Weight:	350 grams (SPM-700-HMB, SPM-800-OHB)
	410 grams (SPM-900-EMB)
BT Version:	3.0
BT Profiles:	HSP, HFP, A2DP, AVRCP
BT Power Class:	Class 2
Sensitivity:	-90 dB
Range (Typical):	10 meters (30 feet)
Built-in Battery:	3.7V, 330mAH Lithium-Ion
Standby Current Draw:	6 mA
Standby Time:	50 hours (max)
Operating Time:	10 hours (max)
Operating Temperature Range:	-15° C to + 50° C

SUPPORT AND WARRANTY

PRYME Radio Products warrants this product against defects in materials or workmanship for a period of one year from the date of retail purchase. PRYME will repair or replace a defective unit, at our option, without charge for parts or labor. The limited warranty is extended only to the original purchaser and is valid only to consumers in the United States and Canada. It does not cover damage or failure caused by or attributable to Acts of God, abuse, misuse, improper or abnormal usage, faulty installation, improper maintenance, lightning, or other incidences of excessive voltage, or any tampering or repairs by other than a PRYME authorized repair facility. It does not cover replacement of consumable parts, transportation costs, or damage in transit.

6

Repair or replacement under the terms of this warranty does not extend the terms of this warranty. This warranty can only be modified by an officer of PRYME Radio Products, and then only in writing. Should this product prove defective in workmanship or material, the consumer's sole remedies shall be such repair or replacement as provided by the terms of this warranty. Under no circumstances shall PRYME Radio Products be liable for any loss or damage, direct, consequential, or incidental, arising out of the use of or inability to use this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which may vary, from state to state.

For support or warranty service on your PRYME product, contact us at 1-800-666-2654 or visit us on the web at www.PRYME.com.

COPYRIGHT and TRADEMARK INFO

© 2021 PRYME Radio Products, Brea CA. All rights reserved.

PRYME® and PRYMEBLU® are trademarks owned by PRYME Radio Products, Brea CA.

All other product or service names are the property of their respective owners.

DISCLAIMER: The BT wireless link used by PRYMEBLU products is an open standard, unsecured technology. As such, it is not recommended for first-responder or other mission critical users.