

















CONNECTOR TABLE

MANUFACTURER	RADIO MODELS	ADAPTER	STYLE	CONNECTOR
RELM	RPU416, RPU4200, RPU499, RPV4200, RPV516, RPV599X		TWO-PIN	x01 (K1) 
RELM	RPU6500 RPV6500 RPU3000A, RPU3600, RPU3600APLUS, RPU7500, RPV3000A, RPV3600, RPV3600APLUS, RPV7500, RPV7500	PA-MLN4455	TWO-PIN	x03 (M1) 
RELM	RPU3000A, RPU3600, RPU3600APLUS, RPU7500, RPV3000A, RPV3600, RPV3600APLUS, RPV7500		MULTI-PIN	x43 (M3) 
SEPURA	STP9000 Series / STP8000. SC20. SC21		MULTI-PIN	SP3 
SEPURA	SRP2000/3000, SRH3500/3800 BOTTOM CONNECTOR		MULTI-PIN	SP4 
TAIT	TP8110. TP8115, TP8120, TP8135, TP8140, TP9300. TP9400		MULTI-PIN	T8 
TAIT	TP8110		TWO-PIN	x03 
VERTEX	FT-10R, FT-250, FT-40R, FT-50R, FT-60R, VX-10, VX-110, VX-150, VX-1R, VX-2E, VX-2R, VX-300, VX-400, VX-5R, VXF-1		ONE-PIN	x02 (Y1) 
VERTEX	VX-530, VX-600, VX-800, VX-900		MULTI-PIN	x12 (Y2) 
VERTEX	VX-130, VX-131, VX-132, VX-160, VX-180, VX-210, VX-210A, VX-230, VX-231, VX-261, VX-350, VX-351, VX-354, VX-400, VX-410, VX-420, VX-427, VX-450, VX-454, VX-459, EVX-261, EVX-530		ONE-PIN	x22s (Y4) 
VERTEX	VX-820, VX-821, VX-824, VX-829, VX-871, VX-874, VX-879, VX-920, VX-921, VX-924, VX-929, VX-971, VX-974, VX-979, VX-P820, VX-P920, VXD-720		MULTI-PIN	x32 (Y3) 
VERTEX	VX-120, VX-127, VX-170, VX-177, VX-6R, VX-7R, EVX-S24		ONE-PIN	x42 
WOXUN, LINTON, PUXING, KIRISUN	KG-UV, DB Series LT-2188/3188/6188 PX-666/777/888/999 FD-268A/B, FO-278, FD-6288		TWO-PIN	x01 (K1) 
Any audio accessory with a 2.5mm phone plug		2.5mm RIGHT ANGLE	x69	
Any audio accessory with a 2.5mm phone plug		2.5mm STRAIGHT	x79	
Any audio accessory with a 3.5mm phone plug		3.5mm RIGHT ANGLE	x89	
Any audio accessory with a 3.5mm phone plug		3.5mm STRAIGHT 2, 3, and 4conductors	x99	