

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting.

RF Exposure Warning!

This device contains transmitters and receivers which emit Radio Frequency (RF) energy. The device is designed to comply with the limits for exposure to RF energy set by the Federal Communications Commission (FCC) of the United States, Industry Canada (IC) of Canada, and the regulating entities of other countries.

If you are still concerned about exposure to RF energy, you can further limit your exposure by limiting the amount of time you use the equipment or by placing more distance between your body and the device, since exposure level drops off dramatically with distance.

2.00.ZUM MARCH 2021

PRYME®

911 Mariner St., Brea, CA 92821
 PH: 714.257.0300 FAX: 714.257.0600
 TOLL FREE: 800.666.2654
 WWW.PRYME.COM

PRYME®

**PRYMEBLU BTH-600-ZU-MOB
 Wireless Speaker Microphone**


For use with Zello on Android smartphones



**Model No. BTH-600-MOB
 Made in Taiwan**

PRYME® and PRYMEBLU® are trademarks owned by PRYME Radio Products, Brea CA. All other product or service names are the property of their respective owners. © 2021 PRYME Radio Products, Brea CA. All Rights Reserved

Controls and Connection



NOTE: The BTH-600_ZU-MOB speaker microphone is powered by an external +5V source within the vehicle. The microphone operates in an "always on" mode as long as power is being supplied. In most applications, it is recommended to tie the external USB power source to vehicle ignition, so that the microphone will automatically power on and off with the vehicle.

Pairing with an Android Handset

The BTH-600-ZU-MOB speaker microphone is designed to work with handsets running the Android operating system. Prior to normal operation, the handset and speaker microphone must be paired together using the following process:



NFC Pairing

1. Make sure that the handset's NFC feature is turned on.
2. Power on the BT speaker microphone by pressing and holding the multifunction button for one second.
3. Touch the BT speaker microphone to the NFC sensor of the phone.
4. A pop-up message should appear on the screen of the phone asking if you would like to pair the two devices. Tap "Yes" to complete the pairing.

Conventional Pairing

1. Activate the pairing mode on the speaker microphone by holding down the pairing button until the status LED flashes BLUE-RED-BLUE-RED continuously in sequence
2. On your phone, go to Settings > BT. Move the BT slider to turn the phone's BT radio on.
3. Select "Search for Devices" from the phone's BT menu. The phone will scan for nearby BT
4. Choose "PTT-600" from the list.
5. Keep the phone and speaker mic near each other and wait a few seconds. The devices will pair to each other.

Reconnecting a Previously Paired Speaker Microphone and Phone

Once the speaker microphone and phone have been successfully paired together, both devices will remember that connection. They will reestablish their link whenever the speaker microphone and phone are both powered on and within range of each other, as long as the BT radio is enabled in the phone. Re-establishing this connection can take 10-60 seconds.

In the event that the phone and speaker microphone do not automatically reestablish their link, simply press the multifunction button on the BTH-600-ZU-MOB to restore the connection.

STATUS LED MESSAGES

The meanings of the various status LED messages shown by the speaker microphone are shown on the following table:

LED INDICATION	MEANING
Constant Red (while plugged into charger)	Charge mode
No indication (while plugged into charger)	Charging is finished
Flashes red-blue-red-blue repeatedly	Pairing mode
Two blue flashes every two seconds	Speaker microphone is powered on but not paired
Three blue flashes every two seconds	Speaker Microphone is powered and paired
Constant red with one blue flash every two seconds	PTT is pressed
No indication	Speaker microphone is powered off

5

Making and Receiving Phone Calls

You can also use the speaker microphone to make and receive phone calls.

- You can initiate a phone call by using the Phone Dialer app in the phone.
- Phone audio will be routed to the BTH-600-ZU-MOB's built-in microphone and speaker (or earphone, if you are using one).
- To answer an incoming call, press the Phone button on the speaker microphone.
- While on a call, you can press the Phone button on the speaker microphone to hang up the phone and end the call.

Resetting the Microphone

Should the need arise, you can reset the BTH-600-ZU-MOB by doing the following:

1. Ensure that the microphone is powered on.
2. Press and hold both the Volume Up and Volume Down buttons for 3-5 seconds, until the microphone emits a beep and the LED on the microphone briefly lights red.

The microphone has now been reset to factory defaults. All previous paired devices have now been forgotten and the BTH-600-ZU-MOB will need to be ready for pairing with a new handset.

SPECIFICATIONS

BT Version:	v4.1
Speaker Output:	2.5 watt
Receiver Sensitivity:	-91 dBm (typ.)
Power Class:	BT class 2
Range:	10 meters
Display:	Blue and Red
BT Profile:	HFP,HSP,AVRCP,A2DP,D1
Operating Voltage:	3.3 VDC
Battery Capacity:	1,020 mAh
Operating Time (Standby):	> 30 days
Operating Time (Typical):	> 80 hours
Operating Time (Continuous Talk):	> 40 hours
Push-to-Talk Function:	Built-in
Operating Temperature:	-4°F to +120°F (approx.)


7

App Setup (ZELLO)

To get the Zello app on your phone, install Zello from your Zello@Work network, or download the app from the Google Play store

Setting up Zello (Android)

1. Make sure that your phone's BT radio is enabled and that the speaker microphone is powered on and that the microphone and phone are connected to each other.
2. Open Zello and go to Menu > Options > Push-to-talk buttons
3. "BTH-600-PTT" should be listed. If it isn't, tap "+ ADD BUTTON" in the top right hand corner of the screen. When prompted, press the PTT button on the BTH-600 microphone. "BTH-600-PTT" should now be shown.
4. Open the Talk screen in Zello (the screen with a big, round button.) In the bottom-left corner of the screen, tap-hold and slide to the BT icon to activate the speaker microphone in Zello.



Once setup, you will be able to use the speaker microphone with the push-to-talk app, even if the app is running in the background.

6

SUPPORT AND WARRANTY

PRYME Radio Products warrants this product against defects in materials or workmanship for a period of one year from the date of retail purchase. PRYME will repair or replace a defective unit, at our option, without charge for parts or labor. The limited warranty is extended only to the original purchaser and is valid only to consumers in the United States and Canada. It does not cover damage or failure caused by or attributable to Acts of God, abuse, misuse, improper or abnormal usage, faulty installation, improper maintenance, lightning, or other incidences of excessive voltage, or any tampering or repairs by other than a PRYME authorized repair facility. It does not cover replacement of consumable parts, transportation costs, or damage in transit.

Repair or replacement under the terms of this warranty does not extend the terms of this warranty. This warranty can only be modified by an officer of PRYME Radio Products, and then only in writing. Should this product prove defective in workmanship or material, the consumer's sole remedies shall be such repair or replacement as provided by the terms of this warranty. Under no circumstances shall PRYME Radio Products be liable for any loss or damage, direct, consequential, or incidental, arising out of the use of or inability to use this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights. You may also have other rights, which may vary, from state to state.

For support or warranty service on your PRYME product, contact us at 1-800-666-2654 or visit us on the web at www.PRYME.com.

COPYRIGHT AND TRADEMARK INFO

© 2021 PRYME Radio Products, Brea CA. All rights reserved.

PRYME® and PRYMEBLU® are trademarks owned by PRYME Radio Products, Brea CA.

Android is a trademark of Google Inc.

ZELLO is a trademark of Zello, Inc..

All other product or service names are the property of their respective owners.

DISCLAIMER: The BT wireless link used by PRYMEBLU products is an open standard, unsecured technology. As such, it is not recommended for first-responder or other mission critical users.

8